LIST

OF

PARTS



MACHINE No. 112-1

THE SINGER MANUFACTURING COMPANY

COPYRIGHT, U. S. A., 1922, BY THE SINGER MANUFACTURING CO.
ALL RIGHTS RESERVED FOR ALL COUNTRIES

INDEX

\mathbf{P}_{I}	AGE
Accessories	13
COOT LIFTER PARTS	13
RON BASE	12
KNEE LIFTER PARTS	13
Machine No. 112-1	7
Numerical List of Parts	17
TABLE SUPPORT PARTS	14
Chread Unwinder	15

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts. must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated. .
- B. Polished and Plated
- C. Hardened only.
- D. Polished only.
- E. Soft, not Polished.
- F. Hardened and Polished.
- G.
- H. Blued.
- J. Plated only.
- K. Hardened and Plated.
- L. Brass or Gilt.
- M. Oxidized.
- P. Japanned.
- R. Parkerized

These letters MUST BE USED when they appear in the list, and AFTER the number as in the list.

In this series

1 to 1500 and 50001 to 51500 are Screw Numbers.

1501 to 1800 are Nut Numbers.

1801 to 2000 are Roller Numbers.

2001 to 50000 and 52001 and upward are numbers of Machine Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

LIST OF PARTS COMPLETE

FOR

MACHINE No. 112-1

FOR WIRING LADIES' HATS, WITH AN OVERSEAMING ZIGZAG STITCH, THROW OF NEEDLE UP TO 18 INCH. DROP FEED, REGULARLY FITTED WITH SWING OUT WORK GUIDE. BALANCE WHEEL AND NEEDLE BAR LEVER ECCENTRIC No. 64807.

NO.	PLATE	NAME
64801		Arm, upper and lower (solid)
34461	8500	" End Cover and Belt Guard
207 b	8507	" Rotary Shaft " Screw
64802	8500	" Rotary Shaft
64803	8501	" " Bushing (front)
1036c	8507	" " " SetScrew
64804	8500	" " " Flanged Bushing (back)
		with 64805
64805	8501	Arm Rotary Shaft Flanged Bushing (back)
		Oil Pad (braided cotton)
1036c	8507	Arm Rotary Shaft Flanged Bushing (back)
		Set Screw
64806	8501	Arm Rotary Shaft Gear with two 200F
200 F	8501	" " Set Serew
64807	8500	Balance Wheel and Needle Bar Lever
		Eccentric with 430c and 1285c
1285c	8507	Balance Wheel and Needle Bar Lever
		Eccentric Position Screw
-430c	8507	Balance Wheel and Needle Bar Lever
		Eccentric Set Screw
64808	8500	Face Plate
$330_{\rm F}$	8507	" " Screw
64809	8500	Feed Bar
64810	8501	" " Connecting Link
428c	8501	" " " Hinge Screw
64811	8509	" " Cover
176г	8507	" " Screw
64812	8501	" " Hinge Stud
452c	8507	" " Set Screw
32055	8501	" Connecting Rod with 1012E, 42009
		and two 1057E

NO. PLATE		NAME	
1042 E - 8501	Feed Connect		usting Screw
*12009	" "	\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \),,,,,,,,,,,,,,,,
1057E 8501			Screw
64813 - 8502			
190ъ 8507			
32057 - 8501			52c
452c 8507	и и		
64814 - 8501			$_{1.452c}$ and $_{462c}$
-64815 - 8501	" "	" Conne	ection with 171E
	and 59019.		
171e 8501	Feed Lifting 1	Eccentric Cor	mection Adjust-
	ing Screw.		
59019 8501	Feed Lifting	Eccentric Co	nnection Gib
50562c 8501		44	" Hinge
	Screw		
1520E 8501	Feed Lifting	Eccentric Co	nnection Hinge
.,,2,,,,	Screw Nut		
452c 8507			ition Screw
462c 8501	" "		Screw
64816 8500			
64817 8501			ushing
1036c 8507	"		" Set Screw
64818 8503	"	" " ('r	ank (back) with
04919 9909	1570		
157 _E 8503	Poul Lifting		Crank (back)
197E 8909			······
64819 8503	Food Lifting	· Rock Shaft	Crank (front)
04019 0000			
157E 8503	Food Lifting	Rock Shaft	Crank (front)
THE COUP	Clamping	, 1000 Share	
1027c 8503	Pool Domila	ing Saran St	ud
	r ced Acgula		
1627c 8503			" Washer
12290 8503			four 452c
64820 8500			ge Pin
59211 8500	**	" iiii	
64821 8503		" "	
1036c 8507			
452c 8507		• •	ge Pin Set Screw
36976 - 5698			
120210 - 5698			
$201 \mathrm{n} \cdot 5698$			
7071 - 8503		" "	$Washer\dots\dots$
36977 5698		i .	
907ъ 5698			<i>.</i>
38676 5698		"	$Washer,\dots\dots$
1074в 8507	" Stud		

	•
NO. PLATE	NAME
793в 8507	Guide Thumb Screw
7071 8503	wasner
36978 - 5698	Guide complete, Nos. 201B, 793B, 1074B,
	36976, 36977, 120210 and two 7071
64822 - 8503	Looper with 34418
64823 8503	" Gate
1240c 8503	" " Hinge Screw
64824 8503	" " Spring
111p 8503	" " Screw
64825 8503	" Shaft with 462c
64826 8503	" Carrier
64827 8503	" " Bushing
846c 8503	" " Set Screw
64828 8504	" " Pitman
(71020 000-	" " " Hinge Screw
1132F 8507	(left)
F0F00 0F01	Looper Shaft Carrier Pitman Hinge Screw
50562c 8501	(right)
4-00 0701	Looper Shaft Carrier Pitman Hinge Screw
1520E 8501	
	(right) Nut
64829 8503	Looper Shaft Coupling with two 462c
462c 8501	Det Belew
462c 8501	" Set Screw
34418 8503	" Washer
64830 8505	Needle Bar (hollow) with 50165r and
	64850
64831 8505	Needle Bar Connecting Bracket with
	1056F and 50203E
50203E 8505	Needle Bar Connecting Bracket Clamping
	Screw
42055 8505	Needle Bar Connecting Link
40247 8505	" " " Hinge Pin
1056F 8505	" " " " Set
	Screw
64832 8504	Needle Bar Frame
64833 8504	" " Cam and Gear
64834 8504	" " " " " Cover
176p 8507	
1.02 000.	Screw
64835 8504	Needle Bar Frame Cam and Gear Stud
01000 0001	(eccentric)
64836 8505	Needle Bar Frame Cam and Gear Stud
04000 0000	Collar with two 1259c
1259c 8505	Needle Bar Frame Cam and Gear Stud
12090 8000	Collar Set Screw
1036c 8507	Needle Bar Frame Cam and Gear Stud
	Set Screw

8849 - 2

NO.	PLATE	NAME
64837	8504	Needle Bar Frame Driving Lever
64838	8505	" " " Connect-
01000	0000	ing Link with 1012b and 59019
1012 p	8501	Needle Bar Frame Driving Lever Connect-
10120	0001	ing Link Adjusting Screw
50010	8501	Needle Bar Frame Driving Lever Connect-
59019	8901	
F0500 .	0501	ing Link Gib
5 0562c	8501	Needle Bar Frame Driving Lever Connect-
****	0501	ing Link Hinge Screw
1520е	8501	Needle Bar Frame Driving Lever Connect-
		ing Link Hinge Screw Nut
64839	8505	Needle Bar Frame Driving Lever Hinge
		Stud
1036c	8507	Needle Bar Frame Driving Lever Hinge
		Stud Set Screw
64840	8505	Needle Bar Frame Guide
176ғ	8507	" " " Screw
37583	8505	" " " Hinge Stud
1036c	8507	" " " Set Screw
64841	8504	" " " Pitman
50562c	8501	" " " Hinge Screw
1520e	8501	
		Nut
64842	8500	Needle Bar Frame Regulator with two
		1120c
64839	8505	Needle Bar Frame Regulator Hinge Stud
64843	8505	
		Bushing
-1259c	8505	Needle Bar Frame Regulator Hinge Stud
		Bushing Set Screw
1984	8505	Needle Bar Frame Regulator Roller and
		Screw Stud
64844	8505	Needle Bar Frame Regulator Stop
	8505	" " " Screw
7806	8505	
• 0,00	0000	Washer
1120e	0507	Needle Bar Frame Regulator Set Screw
1374c		" " Regulating Screw Stud
1680c	8909	
		Nut
42290	8503	Needle Bar Frame Regulating Screw Stud
		Washer
64845	8509	Needle Bar Lever with 1056F and two
		1036c
42074	8505	Needle Bar Lever Ball Stud
1036c		" " " Set Screw

NO.	PLATE	NAME
64846	8504	Needle Bar Lever Connecting Rod with
01010	0001	42059, 64847, 64848 and four 896E
*64847		Needle Bar Lever Connecting Rod Cap
01011		(lower)
808r	8507	Needle Bar Lever Connecting Rod Cap
OJOE	0001	(lower) Screw
*42059		Needle Bar Lever Connecting Rod Cap
12000		(upper)
806r	8507	Needle Bar Lever Connecting Rod Cap
0000	0001	(upper) Screw
42077	8506	Needle Bar Lever Connecting Rod Guide
171F		" " " " " "
1111	0.001	Screw
64848	8501	Needle Bar Lever Connecting Rod Oil
01010	GOOT	Cup
64849	8504	Needle Bar Lever Hinge Stud
64836	8505	" " Collar with
01000	0000	two 1259c
1950c	8505	Needle Bar Lever Hinge Stud Collar Set
12000	0000	Screw
1036c	8507	Needle Bar Lever Hinge Stud Set Screw
64850	8505	" " Washer
50165r		" " Screw
	8505	Needle Clamping Nut
. 64851	8506	Presser Bar
64852	8506	" " Guide Bracket with 1454r
01001	0.3.0	and 50203F
50203ғ	8505	Presser Bar Guide Bracket Adjusting
-		Screw
1454ғ	8506	Presser Bar Guide Bracket Clamping
		Screw
42007	8506	Presser Bar Guide Bracket Guide
452c	8507	" " Set Screw
32123	8506	Presser Bar Lifter
32235	8506	" " " Hinge Stud
452c	8507	" " Set Screw
51807	8506	" " Roller and Screw Stud
64853	8504	" "Spring (flat)
54722	8506	" " Pin
32175	8506	" " Stud
64854	8502	" Foot with 206F and 64855
64878	8502	" " groove, for guiding a
		wire
64879	8502	Presser Foot for straight sewing and
-		binding on wired hat frames
64880	8502	Presser Foot for overseaming chenille or
0.2000		other ornamental edging to straw braid

NO.	PLATE			NA	ME			
64855	8502	Presser	Foot	Exten	sion	. .		
206f	8507	"	46	"	\mathbf{s}	crew		
1761	8507	"	"	Screw				
501321	8507	Pressur	e Reg	ulating	Thur	${ m abSe}$	erew .	
15431	8507	"		"	"		"	Lock
		Nut.						
2102	8506	Tension	n Disc	; 	. .			
1560c	8506	"	Reg	ulating	Thur	nb N	lut	
50261c	8506	"	Scre	w Stuc	1			
54738	8506	"	Spri	ng				
64868	8506	44	Thr	ead Gu	iide			
19068	8506	Thread	Cont	roller	Brack	et		
3301	8507	"		44	"	Se	rew.	
32115	8506	"		" (Guide	Plate	e witl	h 19070
19070	8506	"		"	"	"	Stu	d
64856	8504	"		"	Releas	sing I	Rod.	
59042	8506	"		"	Spring	ζ		
22430	8506	"	Eyel	et (top	of ar	m)		
64857	8506	"	Guai	rd				
1521	8506	46	44	Scre	w			
7071	8503	"	"	**	Wa	sher.	 .	
64858	8502	Throat	Plate	.				
64859	8502	44	46	Need			Strip .	
64860	8502	44	"	46	•	("	Guide
1094	8502	44	"	"	4	•	"	"
		Sere	w					
1931	8502	Throat	Plate	Need	le Hol	e Str	ip Sc	rew
1319	8507	44	"	Screw	z (larg	e)		
2071	8507	"	"	"	(sma	H)		

IRON BASE

NO.	PLATE			NAME
64861	8509	Machine	Base	with three 356c
64862	8508	"	46	Bar
64863	8508	"	"	Foot with 356c
356c	8507	"	"	" Set Screw
356c	8507	"	"	Set Screw
42088	8507	44	Cush	nion (felt)
935E	8507	"	"	' Serew
64864	8509	Machine	Base	complete, Nos. 64861, three
		each 6	4862,	64863, wood screws 1½ in.
		No. 12	and	four each 935E and 42088

ACCESSORIES

NO.	PLATE			-	IAME					
	8508	Machin	e Th	umb	Screv	7 .		 		
14063	8508	44		"	"	Spri	ng	 	-	
9842	8507	"		"	"	Was	her.	 		
36563	8508	Oiler (e	oppe	r pla	ted) v	vith 3	6564	 		
36564	8508					, with				
120117	8508	"								
26151	8508	Screw I								
26485	8508									
8908	8508	Wrench								
19079	8508	"	44	1728				 		

FOOT LIFTER PARTS

NO.	PLATE			NAM				_
6439		Chain,	36 in	ı. to 45	in.,	with	56864	and
		5686	5					
N	OTE: V	Then or	lering	No. 643	39 gi	ve gai	ige req	uired.
	8508			ecting L				
4879				(large).				
56864	8508	"						
56865	8507		"	(small)				
64865	8504	Lifting	; Leve	r				
788u	8507	"	"	Hinge	Scre	W		· · · ·
64866	8500	46	"	Link.				
1250c	8507	"	"	"	Guid	e Scre	w	
1184r	8507	"	"	46	Hing	e Scre	w	
19081	8507	"	"	Spring	g			
59051	8510	Tread	le					
7585	8508	"	Sha	ft				
14210	8510	"		nd				
59052	8510	Tread	le com	plete, N	los. 4	1879, '	7585, 1	4210,
		590	51 an	d four	W000	d scre	ews 1^1	4 in.
		No.	12	,				
64867		East	Lifter	comple	te N	los. 7	88b. 1	184D.
04007		1000	00 64	39, 190	Q1 /	50052	64865	and
		648	ύθ					

KNEE LIFTER PARTS

NO.	PLATE	NAME
59055		Chain, length 18 in., with two 56865
56865	8507	" Hook

NO.	PLATE	NAME	
64865	8504	Lifting Lever	
788n	8507	" " Hinge Screw	
64866	8500	" " Link	
1250c	8507	" " Guide Screw	
1184b	8507	" " " Hinge Screw	
19081	8507	" "Spring	
7124	8509	Rock Shaft	
2764	8509	" " Hanger (back) with two wo	
		screws 1 in. No. 10	
16128	8509	Rock Shaft Hanger (front) with two wo	
		screws 1 in. No. 10	
16646	8509	Rock Shaft Knee Arm	
16647	-	Rock Shaft Knee Arm complete, No	
		2766, 2767 and 16646	
2766	8509	Rock Shaft Knee Arm Hub with 356c.	
356c	8507	" " " Set Screw	
2767	8509	" " Plate with 356c	
356c	8507	" " Set Screw	
6337	8509	" Lifting Bracket with two 35	
6338	8509	" " " Hook	
356c	8507	" " " " " Set Scre	
356c	8507	" " Set Serew	
32134	8509	" " Spring	
2770	8509	" " Adjusting Dog with 350	
356c	8507	""""Set Scre	
2770	8509	" Stop Dog with 356c	
356c	8507	" " Set Screw	
32135	8509	Rock Shaft complete, Nos. 2764, 633	
		6338, 7124, 16128, 16647, 32134 ar	
		three 2770	
64877		Knee Lifter complete, Nos. 788p, 1184	
		1250c, 19081, 32135, 59055, 64865 at	
		64866	

TABLE SUPPORT PARTS


NO.	PLATE	NAME
41044	8510	Base with three wood screws 11/4 in. No. 14
41045	8510	Top with two wood screws 11/4 in. No. 14
41046	8510	Tube
1726г	8508.	" Lock Nut
41047		Table Support Tube complete, Nos. 1726P and 41044 to 41046

THREAD UNWINDER

FOR ONE LARGE SPOOL OR ONE LARGE
CONE OF THREAD

NO.	PLATE	NAME
27623	2836	Spool Pin
155c	8507	" " Set Screw
41526	2836	" Rest
*60701		" 41526 with 155c and 1149c
41527		" " 60701 with 27623
1149c	8507	" Set Screw
27940	2836	" Stand with 453c
41514	2836	" Weight, 4 in. diam., with 41515
41515	8507	" Centre Pin
27739	2836	Thread Cone (wood)
41630	2836	" Guard with 208E and 41569
41569	8507	" " Eyelet
41637	2836	" Rod (lower)
41638	2836	" " (upper)
41639	2836	" " Coupling with two 456c
4560	· ——	" " Set Screw
41640		Thread Guard Rod complete, 30 in. long,
		Nos. 41637 to 41639
4530	8507	Thread Guard Rod Set Screw
208e	e 8507	" Screw
$\dot{4}1529$	2836	Thread Unwinder complete, Nos. 27739,
		27940, 41514, 41527, 41630, 41640 and
		three wood screws, 1 in. No. 12

PLATE 2836-ONE-FOURTH SIZE






PLATE 8501-FULL SIZE u O

